

**MAXX P6 MINI MAXX Peristaltic**  
**portable sampler as compact device (lightweight) for fully automatic sampling system**  
**Peristaltic Pump. Battery operated 12V/9Ah.**

Type	Portable sampler
Housing	ABS / PP
Thermo-Insulation	Insulated base (sample compartment) (insulation thickness 22 – 33 mm)
Control	Microprocessor control, Sleep-Mode (<5mA), power supply 8-16 V foil keyboard (with keys 0-9, ESC, ENT, cursor), graphical display (128*64 Pixel), back lit
Data logger	3000 entries, non-volatile data memory; storage of sampling and malfunction data like sample extractions, bottle changes, messages, external signals. optional with WEB-board 100 MB (2 Year ring memory-FIFO at 1 min interval)
Programming	12 freely programmable user programs, with function to link programs.
Program start options	- IMMEDIATELY; - DATE/TIME - WEEKDAY/TIME; - BY AN EXTERNAL SIGNAL
Program End/Stop options	End of sampling program - AFTER 1 RUN - AFTER X RUNS - CONTINUOUS OPERATION - DATE/TIME
Pause mode	Interruption of program run at any time
Overfilling protection	Adjustable from 1–999 samples/bottles
Interval setting	1 min. to 99 h 59 min. in steps of 1 minute
Pulse setting	1 to 9999 pulses/sample
Manual sample extraction	Possible at any time without interrupting the current program run
Program protection	Up to 5 years after voltage loss
Interface	Mini-USB, optional: Ethernet RJ45, SDI-12
Communication	<p><b>1. Connection via USB and PC (as standard)</b></p> <ul style="list-style-type: none"> <li>• maxxwareConnect® has to be installed on the PC</li> <li>• Connection to the sampler via USB/Mini USB cable</li> <li>• remote control of the sampler</li> <li>• visualization of downloaded data</li> <li>• download and saving of data as PDF, CSV or XLS, or ODT, TXT Format</li> <li>• print-out of data directly as PDF Format</li> <li>• backup of all preprogramed programs from the sampler</li> <li>• setting and saving of programs in offline mode. Upload in online mode</li> <li>• Read out, changing, saving or upload of all sampler programs (1-12)</li> <li>• recovery of saved programs.</li> </ul> <p>or <b>optional:</b></p> <p><b>2. Web Modul LTE-Router / LAN RJ45</b></p> <ul style="list-style-type: none"> <li>• Linux OS</li> <li>• TCP/IP (RJ45)</li> <li>• recording of all CPU Data (like data of sampling cycle, bottle report, error log, temperature etc.)</li> <li>• visualization via Web interface</li> </ul>

	<ul style="list-style-type: none"> <li>• Data-export (PDF, CSV, XLS, ODT, TXT)</li> <li>• E-Mail messaging</li> <li>• FTP-Push</li> <li>• Modbus TCP</li> <li>• Upgrade Sampler-Firmware</li> </ul>
Languages	Multi-language, selectable
Signal inputs	<ul style="list-style-type: none"> <li>• 2 x analog: 0/4-20 mA,</li> <li>• 8 x digital (flow, event, 1 Input can be programmed freely)</li> </ul> <b>option:</b> expandable with 4x digital, 3 inputs can be programmed freely, <ul style="list-style-type: none"> <li>- Impulselength 50ms</li> <li>- working resistance 500 Ohm (analog signal)</li> </ul>
Signal outputs / status messages	<ul style="list-style-type: none"> <li>• 8 digital outputs, 1x of them as collective malfunction message (Relay optional)</li> </ul> <b>option:</b> expandable with 8 digitals, 5 are freely programmable (in total 6 messages)
Sampling method	- Peristaltic Pump 10–10.000 ml
Volume accuracy	Peristaltic pump: +- 5 % at 250ml average of a set of 10 samples
Maximum Lift / Suction height	max. 8 m (at 1013h Pa)
Typical line velocity at Head height:	(at 1013h Pa)
2 m	1,06 m/s
4 m	0,85 m/s
6 m	0,59 m/s
Suction hose	PVC, L=5 m, ID=10 mm, max. hose length 30 m
Sampling modes	<ul style="list-style-type: none"> <li>- <b>Time</b>-related,               <ul style="list-style-type: none"> <li>• Constant Time, Constant Volume (<b>CT, CV</b>)</li> </ul> </li> <li>- <b>Flow</b>-dependent,               <ul style="list-style-type: none"> <li>• Variable Time, Constant Volume (<b>VT, CV</b>)</li> <li>• Constant Time, Variable Volume (<b>CT, VV</b>)</li> </ul>               (Flow modes are controlled by an external flowmeter signal)             </li> <li>- <b>Event</b>-related and</li> <li>- <b>Manual</b> sample extraction.</li> </ul>
Bottle variants	Composite container 10 L PE or 5 L Bottle Glass
Overall dimensions	(D X H) 400 x 605 mm
Weight	approx. 9 kg (without battery, without bottles)
Power supply	<b>Battery:</b> <ul style="list-style-type: none"> <li>➢ 12 V/ 9 Ah lead storage battery (maintenance-free, leak proof);</li> <li>➢ Charger 115V / 230V 2A</li> </ul> <b>operation by mains:</b> Power supply 115V / 230V 7A

Power requirement / number of samples	ca. 70VA Up to 550 sample extractions per battery charge at 1,5 m suction height, depending on ambient conditions.
Ambient temperature	0 to + 50°C
Sample temperature	0 – 40° C
Standards	CE Sampling according to ISO 5667-10, EN16479
Wetted materials	PVC, Silicone, PE, SS304

**Make:** **MAXX**

**Type:** **P6 MINI MAXX Peristaltic**

Manufacturer: MAXX Mess- und Probenahmetechnik GmbH,  
Hechinger Straße 41, D-72414 Rangendingen  
Tel. +49(0)7471-98481 0 Fax +49(0)7471-98481 44  
e-mail: [info@maxx-gmbh.com](mailto:info@maxx-gmbh.com)  
internet [www.maxx-gmbh.com](http://www.maxx-gmbh.com)

Subject to technical changes. \*)